USB DATA ACQUISITION & PROCESSING

12 analog inputs ± 30 V
4 analog inputs ± 400 V
8 digital inputs

16 single-ended / 8 differential channels

16-channel oscilloscope
(With physical values display)

Standalone, powered by USB

Protected case



250 kHz

Simultaneous analog
(single-ended or differential)
and digital inputs

Easy-to-use and intuitive

Adapted to Bac & Bac Pro (French National Education):
. Playful and intuitive setting
. Helpful wiring assistant
. Conversion into physical value (setting by representing the sensor's conversion curve)
. Pictures animated with acquisition data

Adapted to BTS (French National Education):
. Particularly adapted to teaching of systems study in BTS AVA (automotive after-sales)
. Easy to use thanks to various modes of acquisition triggering
. Interpretation of data facilitated by the quality of its graphics and the power and flexibility of its scientific editor

Oscilloscope mode with physical values display



Multiple graphics created by drag & drop managed by tabs with customization of axis



Useful scientific editor

DIDAC BDH SARL – Le moulin du Villaret – 48100 CHIRAC
Tel./ Fax: + 33 (0)4 66 45 88 62

Input channels settings

Channel identification:

Channel conversion:

- into physical value
- into 0 or 1 according to thresholds





- Graphical selection of channels to use by clicking on the image of the case
- Automatic creation of wiring help (printed as table and image).

Data acquisition & recording

Acquisition conditions & Oscilloscope mode:

Acquisition mode

Oscilloscope mode



Acquisition data are recorded in data processing section

Phenomena analysis & data processing

Phenomena analysis & Data processing:



- Multiple views managed by tabs
- Axis customization in each view
- Measurement tools:
  - Slope
  - Tangent line in one point
  - Definite integral with mean value
  - Rising-edge counter
  - Measure of duty cycle
  - Measure of duration and frequency
- Easy data import by « copy & paste»
- Scientific editor:
  - Basic mathematical functions
  - Moving average
  - Data smoothing
  - First and second derivative
  - Primitive – Antiderivative
  - Transformation into 0 or 1 according to thresholds
  - Frequency variation computation
  - Duty cycle variation computation (low and high)



DIDAC BDH SARL – Le moulin du Villaret – 48100 CHIRAC
Tel./ Fax: + 33 (0)4 66 45 88 62